

TAME YOUR TOWELS

Closet Dividers

Give linens and towels dedicated stack-and-store space with wood shelf brackets painted to complement your closet's interior.

You'll Need:

Dutch Boy® Platinum® Plus paint	Painter's tape
Decorative wooden shelf brackets	Wood glue or all-purpose adhesive
Angled paintbrush	Fine- to medium-grit sandpaper
Flat paintbrush	Pencil
Mini woven roller cover and roller frame	Drop cloth
Mini trays	Clean, damp cloth

Here's How:

- Step 1** Wipe interior closet walls and shelving with clean, damp cloth to prepare painting surface.
- Step 2** Lay down the drop cloth to protect floors; affix painter's tape to baseboards, ceiling and any molding or trim.
- Step 3** Using the angled brush, apply paint just inside taped areas, then paint remaining area with the mini woven roller; use the angled brush to paint any built-in shelving and to fill in gaps.
- Step 4** Remove painter's tape while paint is still damp; allow paint to dry, following suggested drying time on paint can label.
- Step 5** Lightly sand any rough or glossy surfaces on the wooden shelf brackets; wipe with clean, damp cloth to remove dust or debris.
- Step 6** Use the flat brush to paint the brackets; allow paint to dry, following suggested drying time on the can label.
- Step 7** Determine the placement of each bracket; use the pencil to lightly mark each position on the shelf.
- Step 8** Apply wood glue to the edges of each bracket and adhere to the shelf; allow to dry completely.

Tip: For added stability, install finishing nails from underneath the shelf through each bracket to secure in place.

Find more paint projects at menards.dutchboy.com/projects.

See paint can labels for application instructions and drying times.

Use Dutch Boy® paint to ensure precise color match. Refer to the actual color chip for accurate color representation.



Closet: Dust Flats 414-1DB