

OVER THE TOP

Front Door Trim Build-out

Give your entryway added dimension and architectural flair by building it out with decorative molding to crown the doorframe.

You'll Need:

Dutch Boy® Exterior paint	Finishing nails
Angled paint brush	Construction adhesive
Paint tray and liners	Precut decorative molding
Painter's tape	Molding blocks (2)
Latex caulk	Drop cloth
Fine- to medium-grit sandpaper	Clean, damp cloth
Tape measure	
Hammer	

Here's How:

- Step 1** Measure width of the doorframe from the outside edges of the trim casing and have decorative molding cut to length.
- Step 2** Install molding and molding blocks with construction adhesive and secure them in place with finishing nails.
- Step 3** Apply latex caulk to any seams and nail holes; use the clean, damp cloth to smooth caulked surfaces and allow to dry, following suggested drying time on label.
- Step 4** Lightly sand any rough or glossy surfaces; wipe with clean, damp cloth to remove dust or debris.
- Step 5** Lay down drop cloth and use painter's tape to protect area around door; tape off any windows.
- Step 6** Using the angled brush, paint molding, molding blocks and doorframe; allow paint to dry, following suggested drying time on the can label; a second coat of paint may be needed.

Find more paint projects at dutchboy.com/projects.

See paint can labels for application instructions and drying times.

Use Dutch Boy® paint to ensure precise color match. Refer to the actual color chip for accurate color representation.



Door: Deep Sky 335-7DB
Trim: Zephyr Breeze 422-1DB
Siding: Cypress Garden 424-4DB